
WS 6 Repair Guide



Parts	Checkpoint 1	Checkpoint 2	Repair method
9 Bearing 608ZZ	a. Check whether the inner and outer rings are spinning in a vortex b. Check whether there is wear and burn on the inner and outer circumference standard size Limits of use A 22 -0.05	a In case the inner and outer rings are not spinning smoothly. b1. In case there is wear on the inner and outer circumference. b2. In case there is burn on the inner and outer circumference.	a. Parts Replacement b1. Above the limit value, replace parts b2. Polish with paper
11 Bevel Gear	a. Check whether there is chips or wear on the gear teeth b. Check there is wear, burn. standard size Limits of use A 1.0 -0.3 B	a1. In case there is scratches, a2. In case there is wear b1. In case there is wear b2. In case there is burn	a1. Parts Replacement a2. Above the limit value, replace parts b1. Above the limit value, replace parts b2. Polish with paper
13 Spindle	Check whether there are burn, wear	In case there is wear In case there is burn	Above the limit value, replace parts Polish with paper
9 Bearing 6302ZZ	a In case the inner and outer rings are not spinning smoothly. b. Check whether there is wear and burn on the inner and outer circumference standard size Limits of use A 42 -0.05 B 15 +0.05 C 13 -0.10	a In case the inner and outer rings are not spinning smoothlyy b. In case there is wear on the inner and outer circumference. c. There is burn on the inner and outer circumference.	a. Parts Replacementb. Above the limit value, replace partsc. Polish with paper

Parts	Checkpoint 1	Checkpoint 2	Repair method
25 Pinion gear	a. Check whether there is chips or wear on the gear teeth b. Check there is wear, burn.	a1. In case there is chips a2. In case there is wear b1. In case there is wear b2. In case there is burn standard size Limits of use A 1.0 -0.3 B \$\phi\$10 -0.03	a1. Parts Replacement a2. Above the limit value, replace parts b1. Above the limit value, replace parts b2. Polish with paper
26 Bearing 6000ZZ	 a. Check whether the inner and outer rings are spinning in a vortex b. Check whether there is wear and burn on the inner and outer circumference 	a In case the inner and outer rings are not spinning smoothly. b1. In case there is wear b2. In case there is burn standard size Limits of use A	a, Parts Replacement b1. Above the limit value, replace parts b2. Polish with paper
27) front plate	 a. Check whether there is corrosion or scratches on outer circumference. b. Check whether the bearing is loose. c. Check whether there is burn, scratches, dent 	a. In case there is corrosion, scratches b. In case the bearing is loose c. In case there is burn, scratches, dent standard size Limits of use a 32.5 -0.03 b 26 +0.03 c The limit of dent -0.04	a. within the limit value, Polish with paper b. Parts Replacement c. within the limit value, Polish with paper

Parts	Checkpoint 1	Checkpoint 2	Repair method
28 Rotor spacer	Check whether there is burn, scratches, wear	In case there is scratches, burn In case there is wear	Polish with paper Above the limit value, replace parts
		standard size Limits of use A φ 10 +0.03 B φ 13.9 -0.03	
29 Rotor		C 3.6 -0.03	
	Check whether there is burn, scratches, wear	In case there is scratches, burn In case there is wear	Polish with paper Above the limit value, replace parts
30 Vane	Check whether there are chips, cracking, wear.	In case there are chips, cracking In case there is wear	a. Parts Replacement b. Above the limit value, replace parts
		standard size Limits of use a 47.8 -0.5 b 8.4 -0.5 c 1.8 -0.2	

Checkpoint 2 **Parts** Checkpoint 1 Repair method a. In case there is corrosion or scratches on outer circumference a. Check whether there is corrosion or a. Polish with paper Cylinder scratches on outer circumference. b. Check whether there is wavefront on the inner surface b. In case there is wavefront on the inner surface. b. Parts Replacement c. Check whether there is burn c. In case there is burn c. Polish with paper Limits of use standard size 32.5 -0.055.75 -0.07Rear plate a. Check whether there is corrosion or a In case there is corrosion or a Polish with paper scratches on outer circumference b. Check whether the bearing is loose. b. In case the bearing is loose b Parts Replacement c. In case there is burn, scratches c Polish with paper c. Check whether there is burn, scratches, dent Limits of use standard size 32.5 -0.05a. Check whether the inner and outer rings a In case the inner and outer rings Bearing 626ZZ a Parts Replacement are not spinning smoothly are not spinning smoothlyv b Check whether there is wear and b1. In case there is wear on the inner and outer circumference. b1 Above the limit value, replace parts burn on the inner and outer circumference. **b2.** There is burn on the inner and outer circumference. b2. Polish with paper Limits of use standard size -0.0519 +0.05 -0.10